

# Installation Instructions

- Begin by removing all carpet and panels from area where material will be applied. Be sure to refer to your vehicles manual for directions on how to properly remove panels.
- Thoroughly clean area where Rockmat will be applied with the included degreaser. Area where material will be applied must be cleaned properly in order for the material to adhere. Allow time for the adhesive to dry completely before continuing with installation.
- Now you are ready to install. Remove the backing from the sheet of Rockmat. We recommend that the installation take place in relatively warm environment. This will allow for better adhesion of the material to the chosen surface. Using the provided roller carefully apply the material to the chosen area ensuring that there are no bumps or air pockets.
- If you are also applying Rockmat to the speaker baffle begin by applying the material. Cut out the speaker hole using a box cutter or Exacto knife.
- Use the material left over from the baffle cut out to apply to the door surface directly behind the speaker in order to improve bass performance.
- Replace all carpet and panels. Now you are ready to rock!
- Visit **RockvilleAudio.com** for installation instructions as well as a short how-to video.

**RM Series** | **ROCKVILLE**  
SOUND DAMPENING MATERIAL