


ROCKVILLE **RRF4** Assembly Instructions

Thank you for purchasing the RRF4 Rack Mount 4 Fan Cooling System with LED Temperature Display. Please read these instructions carefully before use. If you have any questions or need assistance with your installation, please contact our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST. Also you can check out our informational video on YouTube: https://youtu.be/u0w6B5_CNrA or search for Rockville RRF4.



Installation

Installing the RRF4 is quick and easy but there are some things you should know ahead of time in order to further facilitate your installation.

1. A rack space is 1.75" from top to bottom.
2. Equipment height is stated in Rack Units (1.75") and most rack mountable equipment's height is in multiples of 1.75". So, if a unit measures 1U that means that it is 1.75" tall, if it measures 2U then it is 3.5 and so on.
3. The standard width of most racks is 19".
4. Be sure to choose a proper depth rack.
5. Make sure your rack is properly balanced; mount heavier stuff at the bottom and lighter stuff at the top.
6. Make sure to allow for proper airflow.

