

Rockville is proud to introduce one of the most unique items available on the market today. The Rockville Anywhere Karaoke portable, rechargeable Karaoke interface with (2) wireless microphones is the only true sing anywhere device that is on the market today! You can connect this system to a car stereo, TV, home theater system, mixer, portable speaker, or amplifier. It features various audio outputs (3.5mm, RCA) and Bluetooth connectivity for the ultimate in portability.

Please read this guide carefully for proper use of your Rockville Anywhere Karaoke portable, rechargeable Karaoke interface. Should you need technical assistance, please call our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST.

INCLUDES


- Microphone receiver/mixer/interface
- (2) 2.4GHz wireless microphones
- Charging cable
- (1) 3.5mm to 3.5mm AUX cable
- (1) 3.5mm to Dual RCA cable
- Instruction Manual
- Warranty card

IMPORTANT SAFETY INSTRUCTIONS



- To reduce risk of electric shock, never open the unit. There are no user serviceable parts; refer service to an authorized Rockville service center.
- Do not expose this unit to any kind of moisture.
- Please ensure that the unit is situated in a properly ventilated area.

FUNCTIONS




Unit

1. Bluetooth link button
2. LCD display
3. Charging indicator LED
4. Previous/Next FM frequency buttons
5. Power button/Microphone pairing button
6. DC 5V Micro USB charging port
7. 3.5mm audio output
8. 3.5mm audio input

Remote Control


1. FN (long press to pause/play current track)
2. Mute (long press to enter BT pairing mode)
3. Echo (long press for previous track)
4. Mic effect (long press for next track)
5. Music volume -
6. Music volume +
7. Mic volume -
8. Mic volume +
9. Power button/Lock



	Solid green: Connected to receiver. Flashing green: Searching for receiver.
	Solid red: Indicates low battery. Replace the battery as soon as possible.
	Solid yellow: Indicates the mic is in lock mode (mic buttons will not work). Press and hold the button for 3 seconds to exit lock mode.

OPERATION

Power ON: Long press the power button. The unit will automatically enter into Bluetooth pairing mode.



Microphone Pairing

Please note: If using a single mic, it will pair automatically with the receiver. Pairing is only necessary when using two mics and only the first time. Mics should pair automatically when powered on every time thereafter.

1. Make sure both microphones are powered off.
2. Turn on the receiver box. Keep pressing the power button until the MIC 1 indicator flashes quickly (top left hand corner of the display screen) (Fig. 1).
3. Release the power button.
4. Press the power button on MIC 1. The Power button will briefly flash orange, then green, then alternately red and green. At this point the mic will power off and the MIC 1 indicator on the display screen will be solid (Fig. 2).
5. Repeat this procedure to pair MIC 2.

Fig. 1





Fig. 2



Using the Microphones

1. Press the power button on the mic to turn it on. If the microphone is not paired with the receiver, the power button LED will flash green. Refer to the microphone pairing procedures above to connect your mics.
2. You may adjust microphone volume as well as the music volume directly from the microphone. Please refer to the microphone functions section at the top of the page.
3. To activate/adjust echo and mic effects use the corresponding buttons (refer to the microphone functions section above). Each effect features 4 settings. Echo: off, low, medium, and high; Mic effects: normal, low pitch, mid, and high.
4. Long press the Fn button to play/pause current track. Short press the Fn button to activate MPX left/right mono selector (voice cancel).
5. For other microphone functions please refer to the microphone functions section.

Bluetooth Pairing

1. Power ON the converter box; the BT LINK indicator will flash (lower left hand corner of the display screen) and you will hear a tone (Fig. 3).
2. Look for and select Anywhere Karaoke on your Bluetooth device's list of available devices. If pairing is successful, the BT LINK indicator will remain solid and you will hear a tone (Fig. 4).
3. To unpair the unit, press the BT LINK button. The BT LINK indicator will begin to flash and the unit will return to pairing mode (Fig. 5).


Fig. 3



Fig. 4



Fig. 5



FM Radio, Bluetooth

1. Pair your device with the receiver by following the procedure above.
2. Connect the receiver to your car stereo using the FM transmitter (fig. 6) or directly with a 3.5mm to 3.5mm AUX cable (connect to the audio output port of the receiver, Fig. 7). When using the FM transmitter, tune your car radio to a vacant FM station (fig. 8). Use the FM-/FM+ buttons on the receiver to find the same station (Fig. 9).

Fig. 6



Fig. 8




Fig. 7



Fig. 9



CONNECTION OPTIONS

Smart TV

1. Go to www.youtube.com on your smart TV to access karaoke videos (type the name of the song you would like to sing, as well as the word "karaoke" into the youtube search field).
2. Connect the receiver to the RCA input of your smart TV using the included RCA to 3.5mm aux cable.
3. Power ON the receiver, ensuring that the microphones are connected. Now the unit will transmit through your TV's speakers.

Regular TV

1. Connect your laptop to your TV with an HDMI cable (not included) to view karaoke screen on your television. Go to www.youtube.com on your laptop (type the name of the song you would like to sing, as well as the word "karaoke" into the youtube search field).
2. Connect the receiver to the RCA input of your TV using the included RCA to 3.5mm AUX cable.
3. Power ON the receiver, ensuring that the microphones are connected. Now the unit will transmit through your TV's speakers.

Home Theater System

1. Connect your Karaoke viewing screen (laptop, tablet, smartphone, TV) to your home theater system, powered speaker, or mixer in the way you normally would.
2. Turn on the receiver and plug the audio output on the back of the receiver into the RCA input jack of

- your home theater system, powered speaker, or mixer using the included RCA to 3.5mm AUX cable.
3. Power ON the receiver, ensuring that the microphones are connected. The unit will transmit through your selected output device's speakers.

Outdoors

1. Decide which device you would like to use as your Karaoke viewing screen (smartphone, tablet, laptop).
2. Pair the receiver with your device via Bluetooth or the included 3.5mm to 3.5mm AUX cable (connect to the audio input port of the receiver).
3. Connect the receiver to your speaker with a 3.5mm to 3.5mm AUX cable (connect to the audio output port of the receiver). Please note: You may need an additional 3.5mm to 3.5mm cable if you are using the included cable to connect your preferred viewing screen device.
4. Go to www.youtube.com on your device to access karaoke videos (type the name of the song you would like to sing, as well as the word "karaoke" into the youtube search field).

In the Car

1. Decide which device you would like to use as your Karaoke viewing screen (smartphone, tablet, laptop).
2. Pair the receiver with your device via Bluetooth or the included 3.5mm to 3.5mm AUX cable (connect to the audio input port of the receiver).
3. Connect the receiver to your car stereo using the FM transmitter or directly with a 3.5mm to 3.5mm AUX cable (connect to the audio output port of the receiver). When using the FM transmitter, tune your car radio to a vacant FM station. Use the FM-/FM+ buttons on the receiver to find the same station.

Please note: You may need an additional 3.5mm to 3.5mm cable if you are using the included cable to connect your preferred viewing screen device.

4. Go to www.youtube.com on your device to access karaoke videos (type the name of the song you would like to sing, as well as the word "karaoke" into the youtube search field).

An alternate connection method is to connect your device to the car stereo via Bluetooth and connect the receiver to the car stereo using the FM transmitter.

Charging

To charge the receiver, plug it into any 5V power source using the included USB charging cable.

FEATURES

- Rockville Anywhere Karaoke Rechargeable Karaoke Mixer/Interface w/Bluetooth/AUX + (2) Mics
- Audio output allows you to connect this mic system to your car, TV, home theater system, mixer, speaker, or amplifier that has either 3.5mm or RCA inputs.
- FM transmitter allows you to pair, connect and sing karaoke through your car stereo, home receiver or any other radio wirelessly.
- Bluetooth allows you to wirelessly stream music from any Bluetooth enabled device such as your smartphone, tablet, MP3 player, home theater receiver, and more.
- Audio input allows you to plug in any smartphone, MP3 player, tablet, laptop, PC, blue ray player, set-top box, Apple TV, or any other audio device.
- Built-in DSP (Digital signal processing) for digital vocal mixing and echo control.
- Includes (2) digital 2.4GHz wireless microphones with incredible sound clarity.
- Auto power off function turns off the microphone within 2 minutes of non-use to conserve battery life.
- Wireless microphone battery life can reach 28 hours with 2 AA alkaline batteries.
- The wireless microphones can work at a distance of up to 26ft from the receiver
- Microphones feature a low battery indicator
- Each microphone can adjust volume and echo independently
- Receiver is rechargeable, and can be used wirelessly after charged
- Receiver can work up to 16 hours on a single charge
- Receiver charge time is 2 hours
- Receiver can support both Bluetooth and line-in at the same time

SPECIFICATIONS

- Frequency response: 20Hz – 16KHz
- Delay: 13ms – 14ms
- Microphone working time: 28 hours
- Microphone working distance: 26 feet
- 800mAH rechargeable battery
- Low battery reminder and auto power off
- Bluetooth 3.0
- Bluetooth working distance: 32 feet
- Bluetooth auto-connect (connects to Bluetooth device last used)
- Built-in DSP
- 44.1K 16 bit sound quality
- Digital vocal & echo effects
- Each microphone can adjust echo and volume independently
- DC In: 5V
- Single microphone weight: 6.7 ounces
- Microphone Length: 9.1"
- Dimensions of Receiver: 5.6" x 3.1" x .7"
- Receiver weight: 6.3 ounces

TROUBLESHOOTING

No power to receiver or microphones	<ul style="list-style-type: none">• Make sure the battery is fully charged.• If not, plug the unit to a DC 5V power source and charge for 2 hours for a full charge.• Check the mic batteries and replace if necessary (2x AA).
Bluetooth pairing fails	<ul style="list-style-type: none">• Make sure both devices are turned on and that your BT device is discoverable.• Make sure you've selected the proper source.• Make sure the BT device is within 5ft of the unit.• Move both devices away from other BT devices, micro-waves, wireless routers, and other electronics.• Make sure the unit is not paired to another device.
No sound	<ul style="list-style-type: none">• Check all audio connections.• Check microphone batteries. Make sure they are paired to the Anywhere Karaoke receiver.• Make sure the receiver is fully charged.• If using FM transmitter, make sure the receiver frequency matches the radio frequency.• Make sure your playback device is powered on and properly connected.

FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

Responsible party name: Rockville

Address: 600 Bayview Ave,
Entrance A,
Inwood, NY 11096

Hereby declares that the product Rockville Anywhere Karaoke Rechargeable Karaoke Mixer/Interface w/Bluetooth complies with FCC rules as mentioned in the following paragraph:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



ROCKVILLE

Anywhere Karaoke

RECHARGEABLE KARAOKE MIXER/INTERFACE
w/BLUETOOTH/AUX + (2) MICS

Who reads manuals?

Instead, go to vimeo.com/474031278 or scan the QR code to watch the video, which covers everything you need to know to set up this item.





ROCKVILLE

RockvilleAudio.com

© 2020 ROCKVILLE // Features and specifications are subject to change and or improvement without notice.