



# ROCKVILLE



**CYBERBUDS**  
TWS BLUETOOTH 5.0 TRUE WIRELESS  
HEADPHONES EARBUDS+POWERBANK

Thank you for purchasing these Rockville CYBERBUDS TWS Bluetooth Earbuds. Please read this guide carefully for proper use of your CYBERBUDS. Should you need technical assistance please call our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST.

## OVERVIEW



## FUNCTIONS

**Power ON:** The earbuds will automatically power on when they are removed from the charging case. The LED will flash blue and you will hear a voice prompt.

**Power OFF:** The earbuds will automatically power off when they are placed in the charging case. The LED will flash red and you will hear a voice prompt.

**Answering a call:** Short press the MFB on either earbud.

**Ending a call:** Short press the MFB on either earbud.

**Rejecting a call:** Double press the MFB on either earbud.

**Activate Siri:** Triple press the MFB on either earbud.

**Pause/Play:** Short press the MFB on either earbud to play/pause music.

**Vol+/Vol-:** Press and hold the left earbud MFB to decrease volume. Press and hold the right earbud MFB to increase volume.

**Previous/Next track:** Double click the left earbud MFB for previous track. Double click the right earbud MFB for next track.

## OPERATION

### Bluetooth Pairing

- For initial pairing, please make sure your phone is within 3 feet (1 meter) of the earbuds.
  - The earbuds will enter pairing mode automatically once they are removed from the charging case.
  - Look for and select "CYBERBUDS" on your phone's list of available devices. If your phone requests a pin, please use 0000.
  - Upon successful pairing, the LED indicator on the right earbud will flash red & blue and you will hear a voice prompt.
  - To disconnect from a Bluetooth device, place the earbuds back into the charging case. Once they have disconnected, you will hear a tone.
- If pairing is unsuccessful, please repeat the pairing procedure.**

## Please note:

- The earbuds will automatically pair with the last paired device when they are powered on.
- If the headphones go out of Bluetooth range, they will automatically reconnect if they come within 16 feet of the previously paired device before 10 minutes have passed.

## TWS (True Wireless Stereo) Pairing

- The earbuds will automatically connect to each other once they are removed from the charging case.
- Upon successful pairing, the LED indicator on the right earbud will flash red & blue, and you will hear a voice prompt.

## Using a Single Earbud

- To use either earbud individually, simply remove the desired earbud from the charging case.
- If you remove the unused earbud from the charging case within 5 minutes, it will automatically connect to the earbud that is in use.
- To reconnect the earbuds to each other after 5 minutes has passed, place both earbuds into the charging case and remove them together.

## iPhone Operation

- To activate Siri, triple press the MFB on either earbud.
- Once Bluetooth connection is established, the earbud's volume is synchronized with the phone, so that the phone will control the earbuds volume and vice-versa.
- The earbud's power level will be displayed on top right-hand corner of the iPhone screen.

## Charging

CYBERBUDS earbuds feature a 50mAh battery. As the battery becomes

depleted, you will hear various prompts informing you of the battery's power level. When you hear the "please charge now" prompt and the LED flashes red in 1.5 second intervals, place the earbuds in the charging case. They will begin to charge automatically. The charging time is 2 hours.

The charging case features a 1000mAh battery. To charge the case, simply plug the included USB charging cable to the micro USB port at the front of the case. Plug the other end to a USB charging block or a computer/laptop capable of USB charging. When the four LEDs in the case are solid green, the case is fully charged. The charging time is 2 hours.

The case also acts as a power bank to charge other devices that support USB charging. Plug your device's charging cable to the USB output found on the right side of the case. The output power is DC 5.2v/1A.

**Please note:** when the earbuds are disconnected from a Bluetooth device for more than 10 minutes, they will enter Intelligent Sleep mode to help conserve battery life.

## FEATURES

- Bluetooth 5.0 has a long-range signal without dropouts
- 10mm Drivers give amazing bass and crystal clear mids/highs
- High definition audiophile sound quality
- The charging case is also a USB power bank with a built in 1000 mAh battery. You can charge your phone or other electronics with the case.
- IPX6 Waterproof and sweatproof make this perfect for the gym or other outdoor activities
- True Fit ergonomic design fits perfectly in most people's ears comfortably and stays in your ears even while running, jump roping, dancing, etc.
- Turns on automatically when you take it out of the case
- Turns off and charges automatically when you put it back in the case
- LED charging indicator shows you how much battery the case has left
- Built-in microphone allows you to make phone calls
- When making phone calls you will hear the sound from both earbuds
- Earbuds can control volume, track selection, activate Siri, and play/pause
- Travel sized charging case fits in your pocket

## SPECIFICATIONS

- Chipset: AB1526P
- Frequency: 2.4GHz (Class 2)
- Frequency Response: 20Hz – 20KHz
- Sensitivity: -42±3dB
- Output Impedance: 200 ohms
- Mic Impedance: 16 ohms ±15%
- Operating Voltage: 1.5v – 3.6v
- Bluetooth Version: v5.0
- Bluetooth Profiles: HFP 1.7, HSP 1.2, A2DP 1.3, AVRCP 1.6
- Bluetooth Range: 33 ft
- IPX6 Waterproof Rating
- Operating Temperature Range: 32° – 114° F (0° – 45° C)

- Battery Capacity: 1000mAh
- Battery Life: 5 hours
- Standby Time: 80 hours
- Charging Time: Earbuds - 2 hours/Charging Case - 2 hours
- Charging Case Battery Life: 30 hours
- Charging Case Voltage: Input - DC 5.2v/120mA, Output - DC 5.2v/1A

## INCLUDES

- CYBERBUDS TWS Bluetooth Earbuds
- Rubber Ear Tips (x12)
- Charging Case w/Power Bank Functionality
- Micro USB Charging cable
- Owner's Manual

## TROUBLESHOOTING

PROBLEM	SOLUTION
I can pair my earbuds to a Bluetooth device but I cannot hear any music.	<ul style="list-style-type: none"><li>Make sure your device supports the A2DP profile.</li><li>Turn up the volume on your Bluetooth device.</li><li>Unpair your earbuds and re-pair to the device. Follow the steps in the Operations section of this manual, under the heading Bluetooth Pairing.</li><li>Make sure your earbuds are charged.</li></ul>
The earbuds will not go into TWS mode.	<ul style="list-style-type: none"><li>Place both headphones in the charging case and remove them together. Once removed, the headphones will automatically connect to each other.</li><li>Check that the earbuds are charged.</li></ul>
The earbuds will not go into pairing mode.	<ul style="list-style-type: none"><li>Place both headphones in the charging case and remove them together. Once removed, the headphones will automatically enter pairing mode.</li><li>Check that the earbuds are charged.</li></ul>
My Bluetooth device is unable to pair with the earbuds.	<ul style="list-style-type: none"><li>Keep your earbuds and Bluetooth enabled device within 3 feet of each other during the pairing process.</li><li>Check that the device's Bluetooth feature is turned on and try repeating the pairing process.</li></ul>
Should you need further technical assistance please call our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST.	

**RockvilleAudio.com**

© 2020 ROCKVILLE // Features and specifications are subject to change and/or improvement without notice.