

ROCKVILLE

IPS20

TABLET/PHONE TRIPOD STAND-FITS
ALL TABLETS

OWNER'S MANUAL


ATTENTION:
WATCH THIS VIDEO BEFORE FIRST USE!

Who reads manuals?

Scan the **QR code** or go to **rockvillesupport.com/ips20** to access how-to video(s), the owner's manual, and other important information you may need to get the most out of your item.

If you prefer written instructions, please read ahead!

With Rockville you get many options.



Missing items? If you ordered a bundle that includes more than one product and you are missing part of your bundle then it just means your order shipped from two different warehouses. You will receive the remaining items very soon. If you have any concerns or inquiries, feel free to call our customer support center at 1-646-758-0144, 24 hours a day/7 days a week.

ROCKVILLE

ROCKVILLE

Congratulations on your purchase of the Rockville IPS20 Adjustable iPhone/iPod/Tablet/Smartphone Tripod Stand!

The IPS20 stand by Rockville supports most phones and tablets. This stand is made of the same quality materials as our professional microphone stands. It uses strong steel tubing with a long lasting powder-coated finish. It holds screens from 4.7" – 12.9". This means it will work with iPad, iPad mini, iPad pro, iPhone 6, iPhone 7, Samsung Galaxy, and most other tablets and phones. To check if your device is compatible, measure the screen on your device diagonally. If it is within 4.7" – 12.9" then you are good to go.

The IPS20 is fully adjustable. It has a height range of 35.5" – 63". That means you can actually use it while seated or standing! It is fully collapsible for travelling or easy storage. The tablet/phone holder can be oriented horizontally or vertically and it is mounted on a swivel so it can be tilted to any angle.


Please read this guide carefully for proper use of your Rockville IPS20 adjustable tablet/smartphone tripod stand. Should you need technical assistance please call our technical help line at 1-646-758-0144, 24 hours a day/7 days a week.

FEATURES/SPECIFICATIONS


- Rockville IPS20 Tablet/Phone Tripod Stand
- Stand for iPad, iPhone and other tablets/phones from 4.7" – 12.9"
- Adjustable height from 35.5" – 63"
- Tilts +5 degree and -5 degree for different angle viewing
- Sturdy floor base
- Adjustable mounting bracket
- Comfortably use whether standing or sitting
- Perfect for karaoke, speeches, presentations, and more
- Foldable design for easy transportation and storage
- **Holder material:** ABS and rubber surface
- **Stand material:** Steel tubes with powder coating

TABLET/PHONE HOLDER FUNCTIONS

RETRACTED



EXTENDED



To ensure proper use of this product, please carefully read the following instructions:

Assembly:

1. Loosen base screw (fig. a) and pull vertical tube up completely. You will feel resistance once it is fully extended. Tighten base screw (do not over tighten).
2. Fully spread the legs apart (fig. b).
3. Loosen the clamp (fig. c) and adjust extension to the desired height. Tighten clamp, making sure to not over tighten.
4. Tighten the knurled screw until it stops (fig. d).
5. Screw the iPad holder to the threaded pin (fig. e).
6. Now tighten the knurled screw snug to the bottom of the holder (fig. f).
7. Tighten the wing nut at the base of the holder (fig. G).

fig. a



fig. b



fig. c



fig. d





fig. e



fig. f



fig. e



Attaching Tablet/Phone to Holder:

This IPS20 holder allows for adjustment of size, angle, and orientation. All this can be done without removing the iPad.

To adjust angle/orientation:

1. With one hand on the holder, loosen the wing nut (fig. h).
2. Tilt the holder to the desired angle (fig. i).
3. Turn the holder to landscape or vertical position (fig. j)
4. Tighten wing nut. Remember do not over tighten.

fig. h



fig. i






fig. j




To adjust size:

1. Locate the release button on the rear of the holder just to the right of the wing nut (fig. K).
2. Push the button down while simultaneously pulling the top and bottom parts of the bracket. Pull slowly and carefully so as not to damage the mechanism. Once you release the button, the holder will remain in the current extended position.



Rockwell



ROCKVILLE

RockvilleAudio.com

© 2023 ROCKVILLE // Features and specifications are subject to change and/or improvement without notice.