



RDS40


ASSEMBLY GUIDE

Thank you for purchasing the RDS40 Xtra Thickly Padded Portable Deluxe DJ/ Musicians Throne. Please read these instructions carefully before installation. Make sure all parts are included. If any parts are missing please contact our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST.

A		1 piece
B		1 piece
C		1 piece
D		1 piece
E		1 piece
F		1 piece
G		1 piece
H		1 piece
I		1 piece
J		1 piece


STEP 1

Open part A by spreading the feet apart (fig. A). To adjust the height of the foot rest use a wrench to loosen the two lock nuts shown in fig. B. Now you can move the foot rest to the desired height (fig. C). Don't forget to tighten the lock nuts.




STEP 2

Connect part C to part B as indicated in fig. D. Using the screws G & F (fig. E), and the locking nuts, H & I (fig. F) secure part C to part B. Do not over-tighten the locking nuts.



STEP 3

Turn the knob on part A counter-clockwise to remove it. Now insert part B/C into part A until you have achieved the desired height (fig. H). Make sure to align the holes. Once the holes are aligned, reinsert the knob and turn clockwise to tighten (fig. I).



STEP 4

Insert part D into the corresponding slot on the bottom of the seat as indicated in fig. J. Use the locking knob (part J) to secure part D (fig. K). Remove the knob from the back of part E. Now slide part E onto part D (fig. L). Use the knob to secure part E in place (fig. M).

