## ROCKVILLE

RV68.2C 6 x 8"2-Way Component Kit Wiring Diagram

Thank you for purchasing this Rockville SKU. Please read this owner's manual carefully for proper use of your Rockville RV68.2C 6 x 8 2-Way

Thank you for purchasing this Rockville SKU. Please read this owner's manual carefully for proper use of your Rockville RV68.2C 6 x 8 2-Way


Thank you for purchasing this Rockville SKU. Please read this owner's manual carefully for proper use of your Rockville RV68.2C 6 x 8 2-Way

Thank you for purchasing this Rockville SKU. Please read this owner's manual carefully for proper use of your Rockville RV68.2C 6 x 8 2-Way


Thank you for purchasing this Rockville SKU. Please read this owner's manual carefully for proper use of your Rockville RV68.2C 6 x 8 2-Way QR code or go to rockvillesupport.com/rv68-2c to access how-to video(s), the owner's manual, and other important information you may need to get the most out of your item.



## **INSTALLING CROSSOVER**




Remove the crossver's cover by pressing on either side of the cover and pulling up gently.




Use the included long screws to install the crossover as indicated in the illustration.

## **INSTALLING SPEAKER**



To install the speaker, remove the grille from the grille frame (see inset). Now, slide the long screws through the holes in the grill frame and through the corresponding holes in the speaker.

## WIRING THE SYSTEM



Can be wired from the head unit or the amplifier.