



Heavy-Duty Adjustable Pro PA Speaker Stands and XLR Cable Kit

Thank you for purchasing this Rockville RVSS2-XLR Speaker/Lighting Stand. Please read this installation guide carefully for proper use of your Rockville RVSS2-XLR. Should you need technical assistance, please call our technical help line at 1-646-758-0144, Monday through Friday, 9am to 5pm EST.

Congratulations on your purchase of the Rockville RVSS2-XLR Speaker/Lighting Stand!

This heavy-duty universal stand can be used as a Speaker Stand or a Lighting Stand! It's sturdy steel construction and custom carrying case add to the quality and support this stand gives. The sturdy and expandable long tripod legs ensure that your speakers will be stable in any environment. This package also comes with two 20 foot XLR cables!



WEIGHT CAPACITY: 132 lbs

ADJUSTABLE HEIGHT RANGE: 47 - 79 inches


BASE SPREAD: 15 – 40 inches TOP TUBE DIAMETER: 1.37 inches LOWER TUBE DIAMETER: 1.5 inches

LEG DIAMETER: 1.37 inches CONSTRUCTION: Steel

COLOR: Black

XLR CABLE LENGTH: 20 feet





To ensure proper use of this product, please carefully read the following instructions.

Setting up your Rockville speaker stand:

- 1. Unpack thestand and all accessories.
- Loosen up adjustemnt knob A and spread the legs to the desired width (we recommend spreading the legs to the point that the support bars are parallel with floor).
- 3. Re-tighten leg adjustment knob so that the legs are securely positioned.

To mount a speaker:

- 1. Loosen the adjustment knob (see Adjustment Knob "B", facing diagram) and lower the mounting pole until the desired height has been reached.
- 2. Carefully place speaker onto the mounting pole.
- 3. Make sure the silver safety pin (see Safety Pin "C", facing diagram) is removed from the mounting pole and raise the pole to the desired height.
- 4. Tighten adjustment knob "B" at the base of the speaker mounting pole.
- 5. Insert safety pin "C" into its slot to secure desired speaker height.

To remove a speaker:

- 1. Remove safety pin "C".
- 2. Loosen adjustment knob "B".
- 3. Lower the pole to its lowest position.
- 4. Re-tighten adjustment knob "B".
- 5. Carefully remove the speaker from the mounting pole.

Thank you for purchasing this high quality speaker stand. Please read the owner's manual before assembling and be sure to use it properly. An accident or injury can result if the stand is incorrectly assembled or unspecified parts are used. After assembly, keep this manual where it can be consulted when necessary.

Using this product safely and properly

The indicator symbols shown below are used in this manual and on the stand to ensure proper and safe use of the product, to prevent injuries and avoid damage to surrounding items. Please become familiar with these symbols and their associated information before proceeding to the assembly instructions of this manual.



WARNING

This symbol indicates that death or serious injury may result from improper installation if this information is overlooked.



CAUTION

This symbol indicates that injury may result or damage to property could occur from improper installation if this information is overlooked.



WARNING

Do not place this stand on a tall object or high shelf. If the stand were to fall, it could cause an injury.

DO NOT EXCEED INDICATED MAXIMUM WEIGHT CAPACITY.




CAUTION

- This stand is meant for use with speakers ONLY. Do not use the stand for other purposes. Improper use
 of the stand may result in an unstable condition with the potential to cause an injury by falling.
- Assemble the stand on a level surface. Placing the stand on an uneven surface can lead to overturning and
 result in an injury.
- Do not place the stand where people regularly move past it. Bumping into the stand can cause an injury.
- Place the stand on a solid and level floor. Installing the stand in a location that is unstable can cause it to fall and result in an injury.
- Do not drop or drag the stand when assembling or transporting it. Pushing over or dragging the stand can
 result in an injury or cause damage to the floor.
- Do not climb onto or hang from the stand. Be especially careful about children trying to do this. If the stand falls over it can cause an injury.
- This stand is heavy, so be sure 2 or more people cooperate in unpacking or moving it. Improper lifting can
 cause a back injury and dropping the stand can injure feet.

Cautions for Use:

- (1) This is a stand for a speaker system. Avoid using the stand for other purposes.
- (2) The stand is very heavy. Use caution when handling it.
- (3) Place the stand on a solid and level floor. Do not place the stand in an unstable location.
- (4) Be careful not to tip over the stand.
- (5) If the stand becomes dirty, clean it by lightly wiping with a soft cloth and a neutral cleaning solution. Do not use a substance like thinner or benzene.

Thank you for purchasing a Rockville product!



RockvilleAudio.com

Due to constant improvements, these specifications are subject to change without notice. Copyright 2019