

<div><div><div>ROCKVILLE</div><div>RPB50</div><div>PORTABLE BLUETOOTH SPEAKER w/LED and LONG-LIFE BATTERY</div><div>OWNER'S MANUAL</div></div><div><div>ATTENTION:</div><div>WATCH THIS VIDEO BEFORE FIRST USE!</div></div><div><div></div><div>Who reads manuals? Scan the QR code or go to rockvillesupport.com/rpb50 to access how-to video(s), the owner's manual, and other important information you may need to get the most out of your item.</div></div><div><div>Missing items?</div><div>If you ordered a bundle that includes more than one product and you are missing part of your bundle, then it just means your order shipped from two different warehouses. You will receive the remaining items very soon. If you have any concerns or inquiries, feel free to call our customer support center at 1-646-758-0144, 24 hours a day/7 days a week.</div></div></div>	<div><div><div>Thank you for purchasing this Rockville RPB50 Portable Bluetooth Speaker. Please read this owner's manual carefully. Should you need assistance, please call our technical help line at 1-646-758-0144, 24 hours a day/7 days a week.</div><div><div>Included</div><ul style="list-style-type: none">• Bluetooth Speaker• 3.5mm to 3.5mm AUX Cable• USB-C Charging Cable• Owner's Manual• Warranty card</div></div><div><div>IMPORTANT SAFETY INSTRUCTIONS</div><div><div></div><div><ul style="list-style-type: none">• To reduce risk of electric shock, never open the unit. There are no user-serviceable parts, refer service to the Rockville service center.• Do not expose this unit to any kind of moisture.• Please ensure that the unit is situated in a properly ventilated area.• Make sure the unit is placed on a level and stable surface.</div></div></div></div>	<div><div><div>Functions</div><div><div><div>Top Panel</div></div><div><div>Rear Panel</div></div></div><div><div>1. LED light control</div><div>2. — (Previous/Vol-)/+ (Next/Vol+): Press for volume, press and hold for track change.</div><div>3. Play/Pause/Hands Free Call</div><div>4. On/Off, Mode: Press and hold to turn ON/OFF; Short press to change the input source.</div><div>5. Micro SD Card input (supports cards up to 32GB)</div><div>6. USB input (supports cards up to 32GB)</div><div>7. 3.5mm Aux input/Reset button</div><div>8. USB-C charging port (DC 5V)</div></div></div></div>	<div><div><div>BT Pairing</div><div><div>1. Upon powering on, the speaker will automatically enter Bluetooth pairing mode. Please note: if the device is powered on and in another mode, press the Mode button to return to Bluetooth mode. Hold the play button for one second to disconnect current BT device and enter pairing mode.</div><div>2. Ensure your device is in Bluetooth mode and discoverable.</div><div>3. Under your device's list of available devices search for and select RPB50. The unit will automatically connect to your device.</div></div><div><div>! ATTENTION: WHEN PAIRING YOUR BLUETOOTH DEVICE, PLEASE MAKE SURE THE VOLUME ON THE DEVICE IS TURNED UP.</div></div><div><div>BT Playback</div><div>Short press the +/- buttons to raise or lower the volume. Long press the +/- buttons to navigate through tracks. Use the Play/Pause button to control playback. You can also control playback from your playback source.</div></div><div><div>TWS</div><div><div>1. Turn on both units and ensure they are in Bluetooth mode.</div><div>2. Double click the Power button on one of the units. You will hear an audio prompt indicating the unit has entered TWS pairing mode. This will be the master unit and control all playback functionality.</div><div>3. Upon successful pairing, you will hear an audio prompt. Under your device's list of available devices search for and select RPB50. The unit's should now be connected to your device and ready for playback.</div></div></div></div></div>	<div><div><div>Hands-Free Function</div><div>Long press the Play/Pause button to answer or end a call. Double press the button to dial the last called number.</div></div><div><div>USB/SD</div><div><div>1. Insert Micro SD card or USB flash drive (up to 32GB supported) into the corresponding port at the rear of the unit. Alternately, you can press the Mode button to select the desired input source.</div><div>2. Micro SD card/USB input should be automatically recognized and music will begin to play. Please refer to page 5 for supported file formats.</div><div>3. Short press the +/- buttons to raise or lower the volume. Long press the +/- buttons to navigate through tracks. Use the Play/Pause button to control playback.</div></div></div><div><div>Aux Input</div><div>1. Upon plugging in a 3.5mm jack, the unit will automatically switch to Aux input and begin to play music. Please note: If you plug in the 3.5mm cable prior to turning the unit on, use the Mode button to select Aux mode.</div><div>2. Short press the +/- buttons for to raise or lower the volume. Other playback functions can be controlled from your input device.</div></div><div><div>Charging</div><div>The RPB50 uses a 7.4V/4000mAh Lithium-ion battery which supports up to 15 hours playback at 50% volume, 11 hours of playback at 75% volume, 3 hours and 40 minutes of Playback at max volume.</div><div><div>1. Plug the included USB-C cable into the corresponding port on the rear panel.</div><div>2. The LED charging indicator will remain red until the unit is fully charged. Fast charge time is 2 – 3 hours. Normal charging time is 6 – 8 hours.</div></div></div></div>
<div><div><div>LED Lights</div><div><div>1. Press and hold the LED light control button (☼) to turn the LEDs ON or OFF.</div><div>2. Press the LED light control button to cycle through the 8 LED modes.</div></div></div><div><div>Reset</div><div>To reset the unit to factory settings, insert a needle or other thin object into the 3.5mm Aux input to press the reset button located inside.</div></div><div><div>Features and Specifications</div><div><ul style="list-style-type: none">• XL size speaker for deep bass frequencies and very loud overall volume• TWS - True Wireless Stereo Linking of 2 speakers• Two 3" 4 ohm full range speakers and two passive bass radiators for lows• Dual LED rings with 8 LED modes• Bluetooth 5.1 chipset with a 33ft maximum range• Built in micro SD card slot and USB port (supports cards or sticks up to 32GB)• Plays: MP2, MP3, WMA, APE, FLAC, AAC, MP4, M4A, WAV, AIF, AIFC audio• 3.5MM aux input• Rechargeable battery with a fast charge time of 2 – 3 Hours• Battery charges with included Type-C cable• Play, Pause, Skip Forward, Skip Back, Volume Up, Volume Down• Will control playback functions on popular apps like Pandora, Spotify, and other• The built-in microphone allows you to make and receive phone calls hands-free• Carry Handle</div><div><div>Specifications</div><div><ul style="list-style-type: none">• RMS Power: 20w x 2• 7.4V/4000mAh battery</div></div></div></div>	<div><div><div><ul style="list-style-type: none">• Frequency Response: 60Hz – 20kHz• Product Dimensions (Inches): 10.98" L x 5.2" W x 7" H• Product Weight: 3.86 lbs• Color: Black and grey</div><div><div>Troubleshooting</div><div>No power</div><div><div>1. Make sure the unit is powered On.</div><div>2. Make sure the unit is charged. See page 5 for charging instructions.</div></div><div><div>Bluetooth/TWS pairing fails</div><div><div>1. Make sure the unit is powered On.</div><div>2. Ensure that your device is in Bluetooth mode and discoverable.</div><div>3. Make sure you've selected the proper source.</div><div>4. Make sure that the Bluetooth device is within 5 feet of the unit.</div><div>5. Check the speaker and input source volume settings.</div><div>6. Move both devices away from other Bluetooth devices, microwaves, wireless routers, and other electronics.</div><div>7. Make sure that the unit is not paired to a previously paired device.</div></div></div></div><div>Refer to the Bluetooth/TWS instructions on page 4.</div><div><div>No USB/SD playback</div><div><div>1. Make sure the unit is powered On and that you've selected the proper source.</div><div>2. Make sure the USB drive or micro SD card is not damaged.</div><div>3. Ensure the USB drive's or micro SD card's capacity is no more than 32G</div><div>4. make sure that the music files are in the correct format (see page 5).</div></div></div></div></div>	<div><div><div>FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION</div><div><div>Responsible party name: Rockville</div><div>Address: 600 Bayview Ave.</div><div>Entrance A</div><div>Inwood, NY 11096</div></div><div><div>Hereby declares that the product(s) RPB50 complies with FCC rules as mentioned in the following paragraph:</div><div>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div><div>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div><div><ul style="list-style-type: none">• Reorient or relocate the receiving antenna.• Increase the separation between the equipment and receiver.• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.• Consult the dealer or an experienced radio/TV technician for help.</div></div></div></div>		<div><div><div></div><div>ROCKVILLE</div></div><div><div>RockvilleAudio.com</div><div>©2022 ROCKVILLE // The information presented is subject to change and/or improvement without notice.</div></div></div>